

Rear Panel

The VMS1100 rear panel contains ports and connectors for video, audio, RF cabling, data output, and data interface. Some connectors are not enabled and require application software support.




Figure 3 – VMS1100 Rear View

Table 4 – Rear Panel Ports & Connectors

| | PORT/CONNECTOR | DESCRIPTION |
|---|----------------------|--|
| 1 | FiOS TV In | Connects to a coaxial cable that delivers the FiOS signal from your service provider |
| 2 | YPbPr | Connects to the color-coded component video input on a high-definition TV (HDTV) |
| 3 | Audio | Connects to the analog audio left/right stereo inputs on a TV |
| 4 | Digital Audio (RCA)* | Connects to the Dolby® Digital 5.1 audio or PCM output on a digital audio device |
| 5 | M-Card Device Only | Cable card access panel. |
| | | The M-CARD is required to view television programs, previously recorded programs on the DVR, or interactive ondemand programs. The M-CARD should not be removed. |
| 6 | Video Out | Connects to the standard definition video output on an SDTV or VCR |
| 7 | Optical Audio* | Connects to the Dolby® Digital 5.1 audio or PCM output on a digital audio device |
| 8 | НОМІ | Connects to a high-definition TV (HDTV) |
| 9 | USB 2.0* | Connects to a high-speed peripheral device |
| | | |